

TCP

鎖刀座 TOOL TIGHTENING FIXTURE

鎖刀座可任意替換


壓住本體右側之壓閥，可輕易的進行鎖刀座與本體之結合或拆卸。



鎖刀座可360°旋轉

壓住本體上側之定位柱，可輕易的讓鎖刀座做360°(8個45°定位)旋轉

本體底座採用4支M10x40MM螺栓
固定於工作台面或用4支M12螺栓
由工作台面底部反鎖固定



鎖刀座本體



Model No.	kg
TCP-150	6

鎖刀座



Model No.	kg	Model No.	kg
TCP-BT30	2.3	TCP-HSK-A-100	3.8
TCP-BT40	2.8	TCP-HSK-E-25	2.3
TCP-BT50	4.8	TCP-HSK-E-32	2.5
TCP-HSK-A-40	3.3	TCP-HSK-E-40	2.8
TCP-HSK-A-63	2.3	TCP-HSK-E-50	3.0
TCP-HSK-A-80	3.5	TCP-HSK-F-63	3.2

*需搭配本體TCP-150使用